

MCP Brake Bleeder

Step	Instructions	Photo
1	Fill Master Cylinder with DOT 5 Brake Fluid	
2	Close Main Valve and Pinch off Pump Tube	
3	Fill Bleeder Reservoir by removing Fill Screw on side of Reservoir. Once full replace plug. Alternative fill: open Main Valve and pinch off Pump tube, fill through valve end.	
4	Making sure Main Valve is closed, thread onto Master Cylinder and snug up	

5	Open Main Valve and Pump Valve	
6	Apply pressure with 3-4 pumps of pump bulb	
7	Crack both bleeders until stream runs clear with no air	
8	Close bleeders	

9	Pump bulb 1 time	
10	Quickly crack and close each bleeder 1 time... QUICKLY..OPEN AND CLOSE IMMEDIATELY	
11	Shut Main Valve and close bulb valve	

12	Remove bleeder from Master Cylinder	
13	Remove fluid to be 1/16 in. below last thread in Master Cylinder	
14	Replace Master Cylinder Cap	
15	Test brakes *Brakes Should be Firm	